


## INSTALLATION INSTRUCTIONS

### Polaris RZR 1000, Half Windshield

| Description  | Qty |
|--------------|-----|
| Windshield   | 1   |
| Mount Clamps | 4   |

**SuperATV does not recommend keeping Windshield installed while transporting on an open air trailer.**



*Hardware may need to be assembled: Install Insert into Rubber Grommet and wrap Rubber Protector around Clamp.*

**Read instructions and view illustrations before beginning.**

**Need help with your installation?**

✉ sales@superatv.com    🖥 www.superatv.com

☎ 1-812-574-7777    🕒 8:00am - 9:00pm EST M-Th  
8:00am - 7:00pm EST Friday  
9:00am - 2:00pm EST Saturday

*Thank You  
For Choosing*

**Liability Statement**


SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warranted if item was not installed properly, misused, or modified.

1. Insert Rubber Grommets into holes in Windshield. *Tip; apply soapy water to Rubber Grommets.* Inserts go into Rubber Grommets.
2. Install Clamps around Bars.
3. Insert (1) Bolt and (1) Washer through each Rubber Grommet in Windshield.
4. Use Nut to secure Windshield to Clamp.
5. Before tightening completely, push down on top of Windshield so Seal is in contact with Hood.



**Windshield Cleaning:**

- Do not use a dry cloth, or your hands, to wipe off Windshield; Scratching will occur.
  - Do not use window cleaning fluids (Windex, 409, etc) or any solvents (gasoline, denatured alcohol, acetone, etc).
  - Never use abrasive cleaners, abrasive pads, or gritty cloths.
1. Thoroughly rinse Windshield to float off dirt and mud.
  2. Using a soft cloth, or microfiber cloth, clean Windshield with warm water and a gentle detergent. Baby shampoo or hand washing soap are recommended.
  3. To prevent water spots, use a chamois and blot Windshield dry.